

INTEL 8086

Instruction Set

Instruction Description

- **AAA** Instruction - ASCII Adjust after Addition
- **AAD** Instruction - ASCII adjust before Division
- **AAM** Instruction - ASCII adjust after Multiplication
- **AAS** Instruction - ASCII Adjust for Subtraction
- **ADD** Instruction - ADD destination, source
- **ADC** Instruction - Add with carry.
- **AND** Instruction - AND corresponding bits of two operands

AAA Instruction

- AAA converts the result of the addition of two valid unpacked BCD digits to a valid **2-digit BCD number** and takes the **AL register** as its implicit operand.
- Two operands of the addition must have its lower 4 bits contain a number in the range from **0 - 9**
- The AAA instruction **adjust AL** so that it contains a correct BCD digit.
- **If the addition produce carry (AF=1)**, the AH register is incremented and the carry CF and auxiliary carry AF flags are set to 1.
- **If the addition did not produce a decimal carry**, CF and AF are cleared to 0 and AH is not altered.
- In both cases the **higher 4 bits of AL** are cleared to 0.

Example - AAA

- **MOV AH,0** ;Clear AH for MSD
- **MOV AL,6** ;BCD 6 in AL
- **ADD AL,5** ;Add BCD 5 to digit in AL
- **AAA** ;AH=1, AL=1 representing BCD 11.

AAD Instruction

- ADD converts **unpacked BCD digits** in the AH and AL register **into a single binary number** in the AX register in preparation for a **division operation**.
- Before executing AAD, place the Most significant BCD digit in the **AH** register and Last significant in the **AL** register.
- When AAD is executed, the two BCD digits are combined into a single binary number by setting **$AL=(AH*10)+AL$** and clearing AH to 0.
- **After the division** AL will then contain the unpacked BCD quotient and AH will contain the unpacked BCD remainder.

Example - AAD

- `MOV AX,0205h` ;The unpacked BCD number 25
- `AAD` ;After AAD , AH=0 and AL=19h (25)

- **Another Example**

`MOV AX,0607` ;AX=0607 unpacked BCD for 67 decimal

`MOV CH,09` ;CH=09H

- `AAD` ;Adjust to binary before division

`MOV AX,0043` ;AX=0043 = 43H =67 decimal

- `DIV CH` ;Divide AX by unpacked BCD in CH

;AL = quotient = 07 unpacked BCD

;AH = remainder = 04 unpacked BCD

ADD & ADC Instruction

- These instructions **add** a number from **source** to a number from some **destination** and put the result in the specified **destination**.
- The add with carry instruction **ADC**, also add the **status of the carry flag** into the result.
- The source and destination **must be of same type**, means they must be a byte location or a word location.
- **If you want to add a byte to a word**, you must copy the byte to a word location and fill the upper byte of the word with zeros before adding.

Example - ADD & ADC

- **ADD AL,74H** ;Add immediate number 74H to
;content of AL
- **ADC CL,BL** ;Add contents of BL plus
;carry status to contents of CL.
;Results in CL
- **ADD DX, BX** ;Add contents of BX to contents
;of DX
- **ADD DX, [SI]** ;Add content from memory at
;offset [SI] in DS to contents of DX

Example - ADD

Addition of Un Signed numbers

- **ADD** CL, BL ;CL = 01110011 =115 decimal
;+ BL = 01001111 = 79 decimal
;Result in CL = 11000010 = 194 decimal

Addition of Signed numbers

- **ADD** CL, BL ;CL = 01110011 = + 115 decimal
;+ BL = 01001111 = +79 decimal
;Result in CL = 11000010 = - 62 decimal

AND Instruction

AND op1, op2

- This performs a **bitwise Logical AND** of two operands.
- The result of the operation is **stored in the op1** and used to set the flags.
- Each bit of the result is **set to 1** if the corresponding bit in both of the operands are 1.
- Otherwise the bit in the result is cleared to 0 .

Example - AND

- **AND BH, CL** ;AND byte in CL with byte in BH
;result in BH
- **AND BX,00FFh** ;AND word in BX with immediate 00FFH.
;Mask out upper 8 bits of BX
;Result BX = 00000000 01011110
;CF = 0 , OF = 0, PF = 0, SF = 0, ZF = 0
- **AND CX,[SI]** ;AND word at offset [SI] in data
;segment with word in CX
;register . Result in CX register .
;BX = 10110011 01011110

Instruction Description

- **CALL** Instruction - Calling the Procedure
- **CBW** Instruction - Convert signed Byte to signed word
- **CLC** Instruction - Clear the carry flag
- **CLD** Instruction - Clear direction flag
- **CLI** Instruction - Clear interrupt flag
- **CMC** Instruction - Complement the carry flag
- **CMP** Instruction - Compare byte or word
- **CMPS** Instruction - Compare string bytes or string words
- **CMPSB** Instruction - Compare string bytes
- **CMPSW** Instruction - Compare string words
- **CWD** Instruction - Convert Signed Word to Signed Double word

CALL Instruction

- This Instruction is used to transfer execution to a subprogram or procedure.
- There are two basic types of CALL 's : Near and Far.
- Further Divided into:
 - Direct within-segment (near or intrasegment)
 - Indirect within-segment (near or intrasegment)
 - Direct to another segment (far or intersegment)
 - Indirect to another segment (far or intersegment)

Near CALL Instruction

- A **Near CALL** is a call to a procedure which is in the **same code segment** as the **CALL** instruction .
- When 8086 executes the **near CALL** instruction, it decrements the stack pointer by two and **copies the offset** of the next instruction after the **CALL** on the stack.
- This offset saved on the stack is referred as the **return address**, because this is the address that execution will return to after the procedure executes.

Near CALL Instruction

- A **near CALL** instruction will also load the instruction pointer with the offset of the first instruction in the procedure.
- A **RET** instruction at the end of the procedure **will return execution** to the instruction after the **CALL** by **restoring the offset saved on the stack back to IP.**

Far CALL Instruction

- Far **CALL** is a call to a procedure which is in a different segment that which contains the **CALL** instruction.
- When 8086 executes the Far **CALL** instruction, it decrements the stack pointer by two and copies the content of CS register to the stack.
- It then decrements the stack pointer by two again and copies the offset of the instruction after the **CALL** to the stack.

Far CALL Instruction

- Finally it **loads CSR** with segment base of the segment which contains the procedure and **IP** with the offset of the first instruction of the procedure in segment.
- A **RET** instruction at end of procedure will return to the next instruction after the **CALL** by **restoring the saved CS and IP from the stack.**

Example – Near CALL

Direct within-segment (near or intrasegment)

- **CALL MULTO**
 - MULTO is the name of the procedure. The assembler determines displacement of MULTO from the instruction after the CALL and codes this displacement in as part of the instruction .

Indirect within-segment (near or intrasegment)

- **CALL BX**
 - BX contains the offset of the first instruction of the procedure .Replaces contents of IP with contents o register BX.

Example – Far CALL

Direct to another segment (far or intersegment)

- **CALL SMART** ;SMART is the name of the
;Procedure
- **SMART PROC FAR** ;Procedure must be declare as
;an far

CBW Instruction

- **CBW** converts the signed value in the AL register into an equivalent 16 bit signed value in the AX register by duplicating the sign bit to the left.
- This instruction copies the sign of a byte in AL to all the bits in AH.
- AH is then said to be the sign extension of AL.

Example - CBW

- **CBW**

;AX = 00000000 10011011 = - 155 decimal

**;Convert signed byte in AL to signed word in
;AX.**

;Result in AX = 11111111 10011011 = - 155 d

CLC Instruction

- **CLC** clears the carry flag.
- This instruction **has no affect** on the processor, registers, or other flags.
- It is often used to clear the CF **before returning from a procedure** to indicate a successful termination.
- It is also use to clear the CF **during rotate operation** involving the CF such as RCL, RCR.

CLD Instruction

- This instruction resets the direction flag to zero.
- This instruction has no effect on the registers or other flags.
- While executing the string instruction such as **MOVS**, **CMPS**, **SCAS**, **MOVSB** and **STOSB**, if the direction flag is cleared (or reset), **SI** and **DI** will automatically be incremented.

CLI Instruction

- This instruction **resets the interrupt flag to zero.**
- No other flags are affected.
- **If the interrupt flag is reset** , the 8086 will not respond to an interrupt signal on its INTR input.
- This **CLI** instruction has no effect on the non maskable interrupt (NMI) input.

CMC Instruction

- This instruction complements Carry Flag.
- If the carry flag CF is a zero before this instruction, it will be set to a one after the instruction.
- If the carry flag is one before this instruction, it will be reset to a zero after the instruction executes.
- **CMC** has no effect on other flags.

CWD Instruction

- **CWD** converts the 16 bit signed value (**Word**) in the AX register **into** an equivalent 32 bit signed value (**Double Word**) in DX: AX register pair by duplicating the sign bit to the left.
- The **CWD** instruction **sets all the bits in the DX register** to the same sign bit of the AX register.
- The effect is to create a 32- bit signed result that has **same integer value** as the original 16 bit operand.

Example - CWD

- Assume AX contains C435h. If the **CWD** instruction is executed, DX will contain FFFFh since bit 15 (MSB) of AX was 1.
- Both the original value of AX (C435h) and resulting value of DX : AX (FFFFC435h) represents the same signed number.

- Another Example:

```
;DX = 00000000 00000000
```

```
;AX = 11110000 11000111 = - 3897 decimal
```

- **CWD**

```
;Convert signed word in AX to signed double
```

```
;word in DX:AX
```

```
;Result DX = 11111111 11111111
```

```
;AX = 11110000 11000111 = -3897 decimal
```

Instruction Description

- **DAA Instruction** - Decimal Adjust Accumulator
- **DAS Instruction** - Decimal Adjust after Subtraction
- **DEC Instruction** - Decrement destination register / memory
- **DIV Instruction** - Unsigned divide-Div source
- **ESC Instruction**

DIV Instruction

- This instruction is used to **divide an Unsigned word by a byte** or to **divide an unsigned double word by a word**.
- **When dividing a word by a byte** , the word must be in the **AX** register.
- **After the division, AL will contains an 8- bit quotient and AH will contain an 8- bit remainder.**
- If an attempt is made to **divide by 0** or the quotient is too large to fit in AL (greater than FFH), the 8086 will automatically do a type 0 interrupt .

DIV Instruction

- When a double word is divided by a word, the most significant word of the double word must be in DX and the least significant word of the double word must be in AX.
- After the division AX will contain the 16 –bit quotient and DX will contain a 16 bit remainder.
- Again , if an attempt is made to divide by zero or quotient is too large to fit in AX (greater than FFFFH) the 8086 will do a type of 0 interrupt .

DIV Instruction

- For **DIV**, the **dividend** must always be in **AX** or **DX** and **AX**.
- But the **divisor** can be a register or a memory location specified by one of the 24 addressing modes.
- If you want to **divide a byte by a byte**, you must first put the dividend byte in **AL** and fill **AH** with all 0's .
- The **SUB AH,AH** instruction is a quick way to do.
- If you want to **divide a word by a word**, put the dividend word in **AX** and fill **DX** with all 0's.
- The **SUB DX,DX** instruction does this quickly.

Example - DIV

- **DIV BL**

;Word in AX / byte in BL

;Quotient in AL . Remainder in AH.

- **DIV CX**

;(Quotient) AX= (DX:AX)/CX

;(Remainder) DX=(DX:AX)/CX

;AX = 37D7H = 14, 295 decimal

;BH = 97H = 151 decimal

- **DIV BH**

;AX / BH

; AX = Quotient = 5EH = 94 decimal

; AH = Remainder = 65H = 101 decimal

ESC Instruction

- Escape instruction is used to pass instruction to a coprocessor such as the 8087 math coprocessor which shares the address and data bus with an 8086.
- Instruction for the coprocessor are represented by a **6 bit code** embedded in the escape instruction.
- As the 8086 fetches instruction byte, the coprocessor also catches these bytes from data bus and puts them in its queue.
- The coprocessor treats all of the 8086 instruction as an NOP.
- When 8086 fetches an **ESC** instruction , the coprocessor decodes the instruction and carries out the **action specified by the 6 bit code**.

Instruction Description

- **HLT** Instruction - HALT processing
- **IDIV** Instruction - Divide by signed byte or word
- **IMUL** Instruction - Multiply signed number
- **IN** Instruction - Copy data from a port
- **INC** Instruction – Increment
- **INT** Instruction - Interrupt program
- **INTO** Instruction - Interrupt on overflow.
- **IRET** Instruction

HALT Instruction

- The **HLT** instruction will cause the 8086 to **stop fetching and executing instructions.**
- The 8086 will enter to a **halt state.**
- The only way to **get the processor out of the halt state** are with an interrupt signal on the **INTR** pin or an interrupt signal on **NMI** pin or a reset signal on the **RESET** input .

IDIV Instruction

- This instruction is used to divide a signed word by a signed byte or to divide a signed double word by a signed word.
- **IDIV BL** ;Signed word in AX is divided by signed
;byte in BL

Example - IDIV

- **IDIV BP** ;divide a Signed double word in DX and AX by signed word in BP
- **IDIV BYTE PTR[BX]** ;divide AX by a byte at offset [BX] in DS

A signed word divided by a signed byte

;AX = 00000011 10101011 = 03ABH=39 d

;BL = 11010011 = D3H = - 2DH = - 45 decimal

- **IDIV BL** ;Quotient AL= ECH = - 14H = -20 decimal
;Remainder AH = 27H = + 39 decimal

IMUL Instruction

- This instruction performs a **signed multiplication**.
- **IMUL op**
 - In this form the **accumulator** is the **multiplicand** and **op** is the **multiplier**.
 - **op** may be a register or a memory operand.
- **IMUL op1, op2**
 - In this form **op1** is always be a **register operand** and **op2** may be a register or a memory operand.

Example - IMUL

- **IMUL BH** ;Signed byte in AL times multiplied by
;signed byte in BH and result in AX .

69 * 14

;AL = 01000101 = 69 decimal

;BL = 00001110 = 14 decimal

- **IMUL BL**

;AX = 03C6H = + 966 decimal

;MSB = 0 because positive result

- 28 * 59

;AL = 11100100 = - 28 decimal

;BL = 00001110 = 14 decimal

- **IMUL BL**

;AX = F98Ch = - 1652 decimal

;MSB = 1 because negative result

IN Instruction

- This instruction will copy data from a port to the AL or AX register.
- For the Fixed port IN instruction type the 8 bit port address of a port is specified directly in the instruction.
- For a Variable port IN instruction, the 16 bit port address is loaded in DX register before IN instruction.

Example - IN

- **IN** AL, 0C8H ;Input a byte from port 0C8H to AL
- **IN** AX, 34H ;Input a word from port 34H to AX

- A_TO_D **EQU** 4AH
- **IN** AX, A_TO_D ;Input a word from port 4AH to AX

- **MOV** DX, 0FF78H ;Initialize DX point to port
- **IN** AL, DX ;Input a byte from port 0FF78H to AL
- **IN** AX, DX ;Input a word from port
;0FF78H to AX.

Instruction Description

- **JA/JNBE** Instruction - Jump if above/Jump if not below nor equal.
- **JAE/JNB/JNC** Instructions - Jump if above or equal/ Jump if not below/Jump if no carry.
- **JB/JC/JNAE** Instruction - Jump if below/Jump if carry/Jump if not above nor equal
- **JBE/JNA** Instructions - Jump if below or equal/Jump if not above
- **JCXZ** Instruction - Jump if the CX register is Zero
- **JE/JZ** Instruction - Jump if equal/Jump if zero
- **JG/JNLE** Instruction - Jump if greater/Jump if not less than nor equal

Example – JA/JNBE

- **CMP AX, 4371H** ;Compare by subtracting
;4371H from AX
- **JA RUN_PRESS** ;Jump to label RUN_PRESS if
;AX **above** 4371H

- **CMP AX, 4371H** ;Compare (AX – 4371H)
- **JNBE RUN_PRESS** ;Jump to label RUN_PRESS if
;AX **not below or equal** to 4371H

Example – JAE/JNB/JNC

- `CMP AX, 4371H` ;Compare (AX – 4371H)
- `JAE RUN` ;Jump to the label RUN if AX is
;above or equal to 4371H .

- `CMP AX, 4371H` ;Compare (AX – 4371H)
- `JNB RUN_1` ;Jump to the label RUN_1 if AX
;is not below than 4371H

- `ADD AL, BL` ; Add AL, BL. If result is with in
- `JNC OK` ;acceptable range (CF=0), continue.

Example – JB/JC/JNAE

- **CMP AX, 4371H** ;Compare (AX – 4371H)
- **JB RUN_P** ;Jump to label RUN_P if AX is
;below 4371H

- **ADD BX, CX** ;Add two words and Jump to
- **JC ERROR** ; label ERROR if **CF = 1**

Example – JBE/JNA

- **CMP AX, 4371H** ;Compare (AX – 4371H)
- **JBE RUN** ;Jump to label RUN if AX is
;below or equal to 4371H

- **CMP AX, 4371H** ;Compare (AX – 4371H)
- **JNA RUN_R** ;Jump to label RUN_R if AX is
;not above than 4371H

Example – JCXZ

- This instruction performs the **Jump if CX register is zero**.
- **If CX does not contain all zeros**, execution will simply proceed to the next instruction.

```
        JCXZ SKIP_LOOP           ;If CX = 0, skip the process
NXT:    SUB [BX], 07H           ;Subtract 7 from data value
        INC BX                  ; BX point to next value
        LOOP NXT                ; Loop until CX = 0
        SKIP_LOOP              ;Next instruction
```

Example – JE/JZ

```
NXT:    CMP BX, DX        ;Compare ( BX – DX )
        JE DONE         ;Jump to DONE if BX = DX,
        SUB BX, AX      ;Else subtract Ax
        INC CX          ;Increment counter
        JMP NXT         ;Check again
DONE:   MOV AX, CX       ;Copy count to AX

        IN AL, 8FH      ;read data from port 8FH
        SUB AL, 30H     ;AL = AL – 30H
        JZ STATR       ;Jump to label if result of
                       ;subtraction was 0
```


Example – JG/JNLE

CMP BL, 39H ;Compare by subtracting
;39H from BL

JG NEXT1 ;Jump to label if BL is
;more positive than 39H

CMP BL, 39H ;Compare by subtracting
;39H from BL

JNLE NEXT2 ;Jump to label if BL is not
;less than or equal 39H

Instruction Description

- **JGE/JNL** Instruction - Jump if greater than or equal/Jump if not less than
- **JL/JNGE** Instruction - Jump if less than/Jump if not greater than or equal
- **JLE/JNG** Instruction - Jump if less than or equal/Jump if not greater
- **JMP** Instruction - Unconditional jump to specified destination
- **JNA/JBE** Instruction - Jump if not above/Jump if below or equal
- **JNAE/JB** Instruction - Jump if not above or equal/Jump if below
- **JNB/JNC/JAE** Instruction - Jump if not below/Jump if no carry/Jump if above or equal
- **JNE/JNZ** Instruction - Jump if not equal/Jump if not zero
- **JNG/JLE** Instruction - Jump if not greater/ Jump if less than or equal
- **JNGE/JL** Instruction - Jump if not greater than nor equal/Jump if less than

Instruction Description

- **JNL/JGE** Instruction - Jump if not less than/ Jump if greater than or equal
- **JNLE/JG** Instruction - Jump if not less than nor equal to/Jump if greater than
- **JNO** Instruction – Jump if no overflow
- **JNP/JPO** Instruction – Jump if no parity/ Jump if parity odd
- **JNS** Instruction - Jump if not signed (Jump if positive)
- **JNZ/JNE** Instruction - Jump if not zero / jump if not equal
- **JO** Instruction - Jump if overflow
- **JPE/JP** Instruction - Jump if parity even/ Jump if parity
- **JPO/JNP** Instruction - Jump if parity odd/ Jump if no parity
- **JS** Instruction - Jump if signed (Jump if negative)
- **JZ/JE** Instruction - Jump if zero/Jump if equal

JMP Instruction

- **Unconditional jump** to specified destination.

- **Example:**

```
NXT:    CMP BX, DX        ;Compare ( BX – DX )
        JE DONE          ;Jump to DONE if BX = DX,
        SUB BX, AX       ;Else subtract Ax
        INC CX           ;Increment counter
        JMP NXT         ;Check again
DONE:   MOV AX, CX       ;Copy count to AX
```

Example – Different jump instructions

CMP BL, 39H ;Compare by the subtracting 39H from BL
JGE NEXT11 ;Jump to label if BL is more positive than
;39H or equal to 39H

CMP BL, 39H ;Compare by subtracting 39H from BL
JNL NEXT22 ;Jump to label if BL is not less than 39H

CMP BL, 39H ;Compare by subtracting 39H from BL
JL AGAIN ;Jump to the label if BL is more
;negative than 39H

Example – Different jump instructions

CMP BL, 39H ;Compare by subtracting 39H from BL
JNGE AGAIN1 ; Jump to the label if BL is not
;more positive than 39H or
;not equal to 39H

CMP BL, 39h ; Compare by subtracting 39h from BL
JLE NXT1 ;Jump to the label if BL is more
;negative than 39h or equal to 39h

CMP BL, 39h ;Compare by subtracting 39h from BL
JNG AGAIN2 ; Jump to the label if BL is not
;more positive than 39h

Example – Different jump instructions

```
NXT: IN AL, 0F8H      ;Read data value from port
      CMP AL, 72      ;Compare (AL – 72)
      JNE NXT         ;Jump to NXT if AL ≠ 72
      IN AL, 0F9H     ;Read next port when AL = 72
```

```
      MOV BX, 2734H   ; Load BX as counter
NXT_1: ADD AX, 0002H  ;Add count factor to AX
      DEC BX         ;Decrement BX
      JNZ NXT_1      ;Repeat until BX = 0
```

Example – Different jump instructions

ADD AL, BL ;Add signed bytes in AL and BL

JNO DONE ;Process done if no overflow

MOV AL, 00H ;Else load error code in AL

DONE: **OUT 24H, AL** ;Send result to display

IN AL, 0F8H ;Read ASCII char from UART

OR AL, AL ;Set flags

JPO ERROR1 ;If even parity executed, if not
;send error message

Example – Different jump instructions

DEC AL ;Decrement counter

JNS REDO ;Jump to label REDO if counter has not
;decremented to FFH

ADD AL, BL ;Add signed bits in AL and BL

JO ERROR ; Jump to label if overflow occur
;in addition

MOV SUM, AL ;else put the result in memory
;location named SUM

Example – Different jump instructions

```
IN AL, 0F8H      ;Read ASCII char from UART
OR AL, AL        ;Set flags
JPE ERROR2       ;odd parity is expected, if not
                 ;send error message
```

```
ADD BL, DH       ;Add signed bytes DH to BL
JS JJS_S1        ;Jump to label if result is negative
```

Instruction Description

- **LAHF** Instruction - Copy low byte of flag register to AH
- **LDS** Instruction - Load register and DS with words from memory
- **LEA** Instruction - Load effective address
- **LES** Instruction - Load register and ES with words from memory.

LAHF & LDS Instruction

- **LAHF** instruction copies the value of SF, ZF, AF, PF, CF, into bits of 7, 6, 4, 2, 0 respectively of AH register.
- **LDS op1, op2**
- **LDS** instruction loads a far pointer from the memory address specified by op2 into the DS segment register and the op1 to the register.

Example - LDS

- **LDS BX, [4326]**
 - copy the contents of the memory at displacement 4326H in DS to BL, contents of the 4327H to BH.
 - Copy contents of 4328H and 4329H in DS to DSR.

LEA Instruction

- This instruction indicates the offset of the variable or memory location named as the source and put this offset in the indicated 16 bit register.

LEA BX, PRICE ;Load BX with offset of PRICE in DS

LEA BP, SS:STAK ;Load BP with offset of STACK in SS

LEA CX, [BX][DI] ;Load CX with EA=BX + DI

Instruction Description

- **LOCK** Instruction - Assert bus lock signal
- **LODS/LODSB** Instruction - Load string byte into AL
- **LODSW** Instruction - Load string word into AX.
- **LOOP** Instruction - Loop to specified label until CX = 0
- **LOOPE /LOOPZ** Instruction - loop while CX \neq 0 and ZF = 1
- **MOV** Instruction - MOV destination, source
- **MOVS/MOVSb** Instruction - Move string byte
- **MOVSW** Instruction - Move string word
- **MUL** Instruction - Multiply unsigned bytes or words
- **NEG** Instruction - From 2's complement – NEG destination
- **NOP** Instruction - Performs no operation.

LODS/LODSB/LODSW Instruction

- This instruction copies a byte from a string location pointed to by SI to AL or a word from a string location pointed to by SI to AX.
- If DF is cleared to 0, SI will automatically incremented to point to the next element of string.

Example - LODS/LODSB/LODSW

- **CLD** ;Clear direction flag so SI ;is auto incremented
- **MOV SI, OFFSET SOURCE_STRING** ;point SI at start of ;the string
- **LODS SOURCE_STRING** ;Copy byte or word from ;string to AL or AX

LOOP Instruction

- This instruction is used to **repeat** a series of instruction some number of times.

```
MOV BX, OFFSET PRICE ;Point BX at first element in array
MOV CX, 40             ;Load CX with number of elements in array
NEXT: MOV AL, [BX]     ; Get elements from array
ADD AL, 07H           ;Add correction factor
DAA                   ;decimal adjust result
MOV [BX], AL          ; Put result back in array
LOOP NEXT              ; Repeat until all elements adjusted.
```

LOOPE/LOOPZ Instruction

- This instruction is used to repeat a group of instruction some number of times until $CX = 0$ and $ZF = 0$.

```
MOV BX, OFFSET ARRAY    ;point BX at start of the array
```

```
DEC BX
```

```
MOV CX, 100             ;put number of array elements  
                        in CX
```

```
NEXT: INC BX            ;point to next element in array
```

```
CMP [BX], 0FFH         ;Compare array elements FFH
```

```
LOOPE NEXT
```

MOV Instruction

- The **MOV** instruction copies a word or a byte of data from a specified source to a specified destination.

MOV op1, op2

- Examples:

MOV CX, 037AH	;MOV 037AH into the CX.
MOV AX, BX	;Copy the contents of register BX ;to AX
MOV DL,[BX]	;Copy byte from memory at BX ;to DL , BX contains the offset of ;byte in DS.

MUL Instruction

- This instruction performs an **unsigned multiplication** of the accumulator by the operand specified by **op**.
- **op** may be a register or memory operand.

- Example:

MUL **AL** ;AL = 21h (33 decimal)

;BL = A1h(161 decimal)

MUL **BL** ;AX =14C1h (5313 decimal)

MUL **BH** ;AL times BH, result in AX

MUL **CX** ;AX times CX, result high word in DX, low word in AX.

NEG Instruction

- **NEG** performs the **two's complement subtraction** of the operand from zero and **sets the flags** according to the result.

- **Example:**

```
NEG AX ;AX = 2CBh  
;after executing NEG result AX =FD35h.  
NEG AL ;Replace number in AL with its 2's complement  
NEG BX ;Replace word in BX with its 2's complement  
NEG BYTE PTR[BX] ;Replace byte at offset BX in DS with its 2's  
;complement
```

NOP Instruction

- This instruction simply uses up the **three clock cycles** and increments the instruction pointer to point to the next instruction.
- **NOP** does not change the status of any flag.
- The **NOP** instruction is used to **increase the delay** of a delay loop.

Instruction Description

- **NOT** Instruction - Invert each bit of operand.
- **OR** Instruction - Logically OR corresponding of two operands.
- **OUT** Instruction - Output a byte or word to a port.
- **POP** Instruction - POP destination
- **POPF** Instruction - Pop word from top of stack to flag register.
- **PUSH** Instruction - PUSH source
- **PUSHF** Instruction- Push flag register on the stack
- **RCL** Instruction - Rotate operand around to the left through CF
- **RCR** Instruction - Rotate operand around to the right through CF

NOT Instruction

- **NOT** perform the bitwise complement of **op** and stores the result back into **op**.

NOT op

- Examples:

NOT BX ;Complement contents of BX register.

;DX =F038h

NOT DX ;after the instruction DX = 0FC7h

OR Instruction

- **OR** instruction perform the **bit wise logical OR** of two operands.
- Each bit of the result is cleared to 0 if and only if both **corresponding bits in each operand are 0**, other wise the bit in the result is set to 1.

OR op1, op2

- Examples:

OR AH, CL ;CL ORed with AH, result in AH.
;CX = 00111110 10100101

OR CX,FF00h ;OR CX with immediate FF00h
;result in CX = 11111111 10100101
;Upper byte are all 1's lower bytes
;are unchanged.

OUT Instruction

- The **OUT** instruction copies a byte from AL or a word from AX or a double from the accumulator to I/O port specified by **op**.
- **Two forms of OUT** instruction are available:
 1. Port number is specified by an **immediate** byte constant, (0 - 255).It is also called as fixed port form.
 2. Port number is **provided in the DX** register (0 – 65535)

Example - OUT

- **OUT 3BH, AL** ;Copy the contents of the AL to port 3Bh
- **OUT 2CH,AX** ;Copy the contents of the AX to port 2Ch

- **MOV DX, 0FFF8H** ;Load desired port address in DX
- **OUT DX, AL** ;Copy the contents of AL to FFF8h
- **OUT DX, AX** ;Copy content of AX to port FFF8H

POP Instruction

- **POP** instruction copies the word at the current top of the stack to the operand specified by **op** and then increments the stack pointer to point to the next stack.

- Examples:

POP DX ;Copy a word from top of the stack to
;DX and increments SP by 2.

POP DS ;Copy a word from top of the stack to
;DS and increments SP by 2.

POP TABLE [BX] ;Copy a word from top of stack to memory in
;DS with EA = TABLE + [BX].

POPF & PUSH Instruction

- **POPF** Instruction - This instruction copies a word from the two memory location at the top of the **stack to flag register** and increments the stack pointer by 2.
- **PUSH** Instruction - This instruction decrements the stack pointer by 2 and **copies a word from a specified source to the location in the stack segment** where the stack pointer points.
- Examples:

PUSH BX	;Decrement SP by 2 and copy BX to stack
PUSH DS	;Decrement SP by 2 and copy DS to stack
PUSH TABLE[BX]	;Decrement SP by 2 and copy word from ;memory in DS at EA = TABLE + [BX] to stack .

RCL Instruction

RCL op1, op2

- **RCL** instruction rotates the bits in the operand specified by op1 towards left by the count specified in op2.
- The operation is circular, the MSB of operand is rotated into a carry flag and the bit in the CF is rotated around into the LSB of operand.

- Examples:

CLC	;put 0 in CF
RCL AX, 1	;save higher-order bit of AX in CF
RCL DX, 1	;save higher-order bit of DX in CF
ADC AX, 0	;set lower order bit if needed.

Example - RCL

- **RCL DX, 1** ;Word in DX is moved to left by 1bit,
;MSB of word is given to CF and CF to LSB.

;CF=0, BH = 10110011
- **RCL BH, 1** ;Result : BH =01100110
;CF = 1, OF = 1 because MSB changed

;CF =1,AX =00011111 10101001
- **MOV CL, 2** ;Load CL for rotating 2 bit position
- **RCL AX, CL** ;Result: CF =0, OF undefined
;AX = 01111110 10100110

RCR Instruction

RCR op1, op2

- **RCR instruction rotates the bits in the operand specified by op1 towards right by the count specified in op2.**
- **Examples:**

RCR BX, 1

**;Word in BX is rotated by 1 bit towards
;right and CF will contain MSB bit and
;LSB contain CF bit.**

;CF = 1, BL = 00111000

RCR BL, 1

;Result: BL = 10011100, CF = 0

;OF = 1 because MSB is changed to 1.

Instruction Description

- **REP/REPE/REPZ/REPNE/REP NZ** - (Prefix) Repeat String instruction until specified condition exist.
- **RET** Instruction – Return execution from procedure
- **ROL** Instruction - Rotate all bits of operand left, MSB to LSB.
- **ROR** Instruction - Rotate all bits of operand right, LSB to MSB.
- **SAHF** Instruction – Copy AH register to low byte of flag register.
- **SAL/SHL** Instruction - Shift operand bits left, put zero in LSB(s)
- **SAR** Instruction - Shift operand bits right, new MSB = old MSB
- **SBB** Instruction - Subtract with borrow.

ROL Instruction

ROL op1, op2

- **ROL instruction rotates the bits in the operand specified by op1 towards left by the count specified in op2.**
- **ROL moves each bit in the operand to next higher bit position.**
- **The higher order bit is moved to lower order position.**
- **Last bit rotated is copied into carry flag.**

Example - ROL

- **ROL AX, 1** ;Word in AX is moved to left by 1 bit
;and MSB bit is to LSB, and CF

;CF =0 ,BH =10101110
- **ROL BH, 1** ;Result: CF ,Of =1 , BH = 01011101

;BX = 01011100 11010011
;CL = 8 bits to rotate
- **ROL BH, CL** ;Rotate BX 8 bits towards left
;CF =0, BX =11010011 01011100

ROR Instruction

ROR op1, op2

- **ROR** instruction **rotates** the bits in the operand op1 **towards right** by count specified in op2.
- The last bit rotated is copied into CF.

ROR BL, 1 ;Rotate all bits in BL towards right by 1
;bit position, LSB bit is moved to MSB
;and CF has last rotated bit.

Example - ROR

- **ROR** BX, 1

;CF =0, BX = 00111011 01110101

;Rotate all bits of BX of 1 bit position

;towards right. Then CF =1 and

;BX = 10011101 10111010

- **MOV** CL, 04H

;CF = 0, AL = 10110011,

;Load CL

- **ROR** AL, CL

;Rotate all bits of AL towards right

;by 4 bits, CF = 0 ,AL = 00111011

SAHF Instruction

- **SAHF** copies the value of bits 7, 6, 4, 2, 0 of the **AH** register into the **SF**, **ZF**, **AF**, **PF**, and **CF** respectively.
- This instruction was provided to make easier **conversion of assembly language program** written for 8080 and 8085 to 8086.

SAL/SHL Instruction

SAL op1,op2

- **SAL** instruction **shifts** the bits in the operand specified by **op1** to its **left** by the count specified in **op2**.
- As a bit is shifted out of LSB position, a '0' is kept in LSB position.
- CF will contain MSB bit.

- Example:

```
SAL BX, 1           ;CF = 0, BX = 11100101 11010011
                    ;Shift BX register contents by 1 bit
                    ;position towards left
                    ;CF = 1, BX = 11001011 1010011
```


SAR Instruction

SAR op1, op2

- **SAR** instruction shifts the bits in the operand specified by **op1** towards right by count specified in **op2**.
- As bit is shifted out a copy of old **MSB** is taken as **MSB** position and **LSB** is shifted to **CF**.

- Examples:

SAR AL, 1

;AL = 00011101 = +29 decimal, CF = 0
;Shift signed byte in AL towards right
;AL = 00001110 = + 14 decimal, CF = 1

SAR BH, 1

;BH = 11110011 = - 13 decimal, CF = 1
;Shifted signed byte in BH to right
;BH = 11111001 = - 7 decimal, CF = 1

SBB Instruction

- **SUBB** instruction subtracts op2 from op1 and then subtracts 1 from op1 if CF flag is set.
- Result is stored in op1 and it is used to set the flag.
- Example:

SUB CX, BX ;CX – BX, Result in CX

SUBB CH, AL ;Subtract contents of AL and
;Carry Flag from content of CH
;Result in CH

SUBB AX, 3427H ;Subtract immediate number from AX

Instruction Description

- **STD** Instruction - Set the direction flag to 1.
- **STI** Instruction - Set interrupt flag (IF).
- **STOS/STOSB/STOSW** Instruction - Store byte or word in string.
- **SCAS/SCASB/SCASW** Instruction - Scan string byte or word.
- **SHR** Instruction - Shift operand bits right, put zero in MSB
- **STC** Instruction - Set the carry flag to 1

SHR Instruction

- **SHR** instruction shifts the bits in **op1** to right by the number of times specified by **op2** .
- Example:

SHR BP, 1 ;Shift word in BP by 1 bit position to right
;and 0 is kept to MSB

MOV CL, 03H ;Load desired number of shifts into CL

SHR BYTE PTR[BX] ;Shift bytes in DS at offset BX
;and rotate 3 bits to right and
;keep 3 0's in MSB

SHR SI, 1 ;SI = 10010011 10101101 , CF = 0
;Result: SI = 01001001 11010110
;CF = 1, OF = 1, SF = 0, ZF = 0

Instruction Description

- **TEST** Instruction – AND operand to update flags
- **WAIT** Instruction - Wait for test signal or interrupt signal
- **XCHG** Instruction – Exchange - XCHG destination, source
- **XLAT/XLATB** Instruction - Translate a byte in AL
- **XOR** Instruction - Exclusive OR corresponding bits of two operands

TEST Instruction

- This instruction **ANDs** the contents of a source byte or word **with the contents of specified destination word**.
- **Flags are updated** but neither operand is changed.
- **TEST** instruction is often **used to set flags** before a condition jump instruction.

```
TEST AL, BH           ;AND BH with AL. No result is  
                        ;stored . Update PF, SF, ZF
```

Example - TEST

- **TEST CX, 0001H**

**;AND CX with immediate number
;no result is stored, Update PF & SF**

- **TEST AL, 80H**

;AL = 01010001

**;AND immediate 80H with AL to
;test whether MSB of AL is 1 or 0**

;ZF = 1 if MSB of AL = 0

;AL = 01010001 (unchanged)

;PF = 0 , SF = 0

;ZF = 1 because ANDing produced is 00

WAIT Instruction

- When this **WAIT** instruction executes, the 8086 enters an **idle condition**.
- This will stay in this state until a signal is asserted on **TEST input pin** or a **valid interrupt signal** is received on the **INTR or NMI pin**.

XCHG Instruction

- The **Exchange instruction** exchanges:
 - *the contents of the register with the contents of another register*
 - or
 - *the contents of the register with the contents of the memory location.*
- Direct memory to memory exchange are not supported.

XCHG op1, op2

- The both operands must be the same size and **one of the operand must always be a register** .

Example - XCHG

XCHG AX, DX ;Exchange word in AX with word in DX

XCHG BL, CH ;Exchange byte in BL with byte in CH

XCHG AL, Money [BX] ;Exchange byte in AL with byte
;in memory at EA.

XOR Instruction

XOR op1, op2

- **XOR** performs a **bit wise logical XOR** of the operands specified by **op1** and **op2**.
- The **result** of the operation is stored in **op1** and is used to set the **flag**.
- Example:

```
XOR BX, CX      ;BX = 00111101 01101001  
                  ;CX = 00000000 11111111  
                  ;Exclusive OR CX with BX  
                  ;Result BX = 00111101 10010110
```